



virtutech

Simics/PPC64-Simple Target Guide

Simics Version 3.0

Revision 1376

Date 2007-01-24

VIRTUTECH CONFIDENTIAL

© 1998–2006 Virtutech AB
Norrtullsgatan 15, SE-113 27 STOCKHOLM, Sweden

Trademarks

Virtutech, the Virtutech logo, Simics, and Hindsight are trademarks or registered trademarks of Virtutech AB or Virtutech, Inc. in the United States and/or other countries.

The contents herein are Documentation which are a subset of Licensed Software pursuant to the terms of the Virtutech Simics Software License Agreement (the “Agreement”), and are being distributed under the Agreement, and use of this Documentation is subject to the terms the Agreement.

This Publication is provided “as is” without warranty of any kind, either express or implied, including, but not limited to, the implied warranties of merchantability, fitness for a particular purpose, or non-infringement.

This Publication could include technical inaccuracies or typographical errors. Changes are periodically added to the information herein; these changes will be incorporated in new editions of the Publication. Virtutech may make improvements and/or changes in the product(s) and/or the program(s) described in this Publication at any time.

Contents

| | | |
|----------|--|-----------|
| 1 | About Simics Documentation | 5 |
| 1.1 | Conventions | 5 |
| 1.2 | Simics Guides and Manuals | 5 |
| | Simics Installation Guide for Unix and for Windows | 5 |
| | Simics User Guide for Unix and for Windows | 6 |
| | Simics Eclipse User Guide | 6 |
| | Simics Target Guides | 6 |
| | Simics Programming Guide | 6 |
| | DML Tutorial | 6 |
| | DML Reference Manual | 6 |
| | Simics Reference Manual | 6 |
| | Simics Micro-Architectural Interface | 6 |
| | RELEASENOTES and LIMITATIONS files | 7 |
| | Simics Technical FAQ | 7 |
| | Simics Support Forum | 7 |
| | Other Interesting Documents | 7 |
| 2 | Simics/PPC64-Simple Overview | 8 |
| 3 | Simulated Machines | 9 |
| 3.1 | Yellow | 9 |
| | 3.1.1 Yellow Scripts | 9 |
| 3.2 | Parameters for Machine Scripts | 9 |
| | 3.2.1 yellow-common | 9 |
| 4 | Supported Components | 11 |
| 4.1 | Yellow Components | 11 |
| 4.2 | Standard Components | 11 |
| | 4.2.1 std-ethernet-link | 11 |
| | 4.2.2 std-serial-link | 12 |
| | 4.2.3 std-text-console | 13 |
| | 4.2.4 std-server-console | 14 |
| 4.3 | Base Components | 15 |
| | 4.3.1 component | 15 |
| | 4.3.2 top-component | 16 |

| | | |
|----------|--|-----------|
| 5 | Miscellaneous Notes | 17 |
| 5.1 | Changing the Processor Clock Frequency | 17 |
| 5.2 | Manually Testing Interrupts | 17 |
| 5.3 | Cache Simulation | 18 |
| 6 | Limitations | 19 |
| 6.1 | PowerPC 970fx limitations | 19 |
| 6.1.1 | Unsupported SPRs | 19 |
| 6.1.2 | Miscellaneous Processor Core Limitations | 19 |
| 6.1.3 | Unimplemented Instructions | 19 |
| 6.1.4 | Instructions Implemented as NOPs | 19 |
| 7 | References | 20 |
| | Index | 21 |

Chapter 1

About Simics Documentation

1.1 Conventions

Let us take a quick look at the conventions used throughout the Simics documentation. Scripts, screen dumps and code fragments are presented in a monospace font. In screen dumps, user input is always presented in bold font, as in:

```
Welcome to the Simics prompt
simics> this is something that you should type
```

Sometimes, artificial line breaks may be introduced to prevent the text from being too wide. When such a break occurs, it is indicated by a small arrow pointing down, showing that the interrupted text continues on the next line:

```
This is an artificial ↴
line break that shouldn't be there.
```

The directory where Simics is installed is referred to as `[simics]`, for example when mentioning the `[simics]/README` file. In the same way, the shortcut `[workspace]` is used to point at the user's workspace directory.

1.2 Simics Guides and Manuals

Simics comes with several guides and manuals, which will be briefly described here. All documentation can be found in `[simics]/doc` as Windows Help files (on Windows), HTML files (on Unix) and PDF files (on both platforms). The new Eclipse-based interface also includes Simics documentation in its own help system.

Simics Installation Guide for Unix and for Windows

These guides describe how to install Simics and provide a short description of an installed Simics package. They also cover the additional steps needed for certain features of Simics to work (connection to real network, building new Simics modules, ...).

Simics User Guide for Unix and for Windows

These guides focus on getting a new user up to speed with Simics, providing information on Simics features such as debugging, profiling, networks, machine configuration and scripting.

Simics Eclipse User Guide

This is an alternative User Guide describing Simics and its new Eclipse-based graphical user interface.

Simics Target Guides

These guides provide more specific information on the different architectures simulated by Simics and the example machines that are provided. They explain how the machine configurations are built and how they can be changed, as well as how to install new operating systems. They also list potential limitations of the models.

Simics Programming Guide

This guide explains how to extend Simics by creating new devices and new commands. It gives a broad overview of how to work with modules and how to develop new classes and objects that fit in the Simics environment. It is only available when the DML add-on package has been installed.

DML Tutorial

This tutorial will give you a gentle and practical introduction to the Device Modeling Language (DML), guiding you through the creation of a simple device. It is only available when the DML add-on package has been installed.

DML Reference Manual

This manual provides a complete reference of DML used for developing new devices with Simics. It is only available when the DML add-on package has been installed.

Simics Reference Manual

This manual provides complete information on all commands, modules, classes and haps implemented by Simics as well as the functions and data types defined in the Simics API.

Simics Micro-Architectural Interface

This guide describes the cycle-accurate extensions of Simics (Micro-Architecture Interface or MAI) and provides information on how to write your own processor timing models. It is only available when the DML add-on package has been installed.

RELEASENOTES and LIMITATIONS files

These files are located in Simics's main directory (i.e., [simics]). They list limitations, changes and improvements on a per-version basis. They are the best source of information on new functionalities and specific bug fixes.

Simics Technical FAQ

This document is available on the Virtutech website at <http://www.simics.net/support>. It answers many questions that come up regularly on the support forums.

Simics Support Forum

The Simics Support Forum is the main support tool for Simics. You can access it at <http://www.simics.net>.

Other Interesting Documents

Simics uses Python as its main script language. A Python tutorial is available at <http://www.python.org/doc/2.4/tut/tut.html>. The complete Python documentation is located at <http://www.python.org/doc/2.4/>.

Chapter 2

Simics/PPC64-Simple Overview

Simics/PPC64-Simple models a simple PPC64 system with a PPC970FX processor. Virtutech provides images to run Linux on the machines.

Chapter 3

Simulated Machines

Simics scripts for starting PPC64-Simple machines are located in the `[workspace]/targets/ppc64-simple/` directory, while the actual configuration scripts can be found in `[simics]/targets/ppc64-simple/`.

3.1 Yellow

The default configuration can be modified as described in section [3.2](#).

3.1.1 Yellow Scripts

This chapter explains the files used to boot Linux on Yellow.

`yellow-common.simics`

Starts the yellow machine with the default configuration.

3.2 Parameters for Machine Scripts

The following parameters can be set before running the `yellow-common.simics` scripts.

3.2.1 `yellow-common`

`$freq_mhz`

The clock frequency in MHz for the processor.

`$memory_megs`

Amount of RAM in megabytes installed.

`$kernel_image`

The Linux kernel image file that should be booted.

`$initrd_image`

The file containing the initrd ram disk for Linux.

\$kernel_base

The address to which the kernel binary is linked..

\$load_base

The kernel binary is linked to virtual address *\$kernel_base*, but yaboot will load it somewhere in the low 32 bit address space. The *\$load_base* parameter is this base address.

Chapter 4

Supported Components

The following sections list components that are supported for the PPC64-Simple architecture. There also exist other components in Simics, such as various PCI devices, that may work for PPC64-Simple but that have not been tested.

The default machines are constructed from components in the `-system.include` files in `[simics]/targets/ppc64-simple/`. See the Configuration and Checkpointing chapter in the Simics User Guide for information on how to define your own machine, or make modifications to an existing machine.

4.1 Yellow Components

4.2 Standard Components

4.2.1 std-ethernet-link

Description

The “std-ethernet-link” component represents a standard Ethernet link.

Attributes

frame_echo

Optional attribute; **read/write** access; type: **Integer**.

Set this attribute to echo frames back to the sender. Default is not to echo frames.

link_name

Optional attribute; **read/write** access; type: **String**.

The name to use for the **ethernet-link** object. An error will be raised at instantiation time if the link cannot be given this name.

Commands

create-std-ethernet-link [*name*] [*link_name*] [*frame_echo*]

Creates a non-instantiated component of the class “std-ethernet-link”. If *name*

is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

new-std-ethernet-link [*name*] [*link_name*] [*frame_echo*]

Creates an instantiated component of the class "std-ethernet-link". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

<std-ethernet-link>.info

Print detailed information about the configuration of the device.

<std-ethernet-link>.status

Print detailed information about the current status of the device.

Connectors

| Name | Type | Direction |
|--------|---------------|-----------|
| device | ethernet-link | any |

4.2.2 std-serial-link

Description

The "std-serial-link" component represents a standard Serial link.

Commands

create-std-serial-link [*name*]

Creates a non-instantiated component of the class "std-serial-link". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

new-std-serial-link [*name*]

Creates an instantiated component of the class "std-serial-link". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

<std-serial-link>.info

Print detailed information about the configuration of the device.

<std-serial-link>.status

Print detailed information about the current status of the device.

Connectors

| Name | Type | Direction |
|-------------|--------|-----------|
| serial[0-1] | serial | any |

4.2.3 std-text-console**Description**

The “std-text-console” component represents a serial text console.

Attributes*bg_color*

Optional attribute; **read/write** access; type: **String**.
The background color.

fg_color

Optional attribute; **read/write** access; type: **String**.
The foreground color.

height

Optional attribute; **read/write** access; type: **Integer**.
The height of the console window.

title

Optional attribute; **read/write** access; type: **String**.
The Window title.

width

Optional attribute; **read/write** access; type: **Integer**.
The width of the console window.

win32_font

Optional attribute; **read/write** access; type: **String**.
Font to use in the console on Windows host.

x11_font

Optional attribute; **read/write** access; type: **String**.
Font to use in the console when using X11 (Linux/Solaris host).

Commands

create-std-text-console ["name"] ["title"] ["bg_color"] ["fg_color"] ["x11_font"] ["win32_font"] [width]

Creates a non-instantiated component of the class "std-text-console". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

new-std-text-console ["name"] ["title"] ["bg_color"] ["fg_color"] ["x11_font"] ["win32_font"] [width]

Creates an instantiated component of the class "std-text-console". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

<std-text-console>.info

Print detailed information about the configuration of the device.

<std-text-console>.status

Print detailed information about the current status of the device.

Connectors

| Name | Type | Direction |
|--------|--------|-----------|
| serial | serial | up |

4.2.4 std-server-console

Description

The "std-server-console" component represents a serial console accessible from the host using telnet.

Attributes

telnet_port

Required attribute; **read/write** access; type: **Integer**.

TCP/IP port to connect the telnet service of the console to.

Commands

create-std-server-console ["name"] *telnet_port*

Creates a non-instantiated component of the class "std-server-console". If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

new-std-server-console [*name*] *telnet_port*

Creates an instantiated component of the class “std-server-console”. If *name* is not specified, the component will get a class-specific default name. The other arguments correspond to class attributes.

<std-server-console>.info

Print detailed information about the configuration of the device.

<std-server-console>.status

Print detailed information about the current status of the device.

Connectors

| Name | Type | Direction |
|--------|--------|-----------|
| serial | serial | up |

4.3 Base Components

The base components are abstract classes that contain generic component attributes and commands available for all components.

4.3.1 component

Description

Base component class, should not be instantiated.

Attributes*connections*

Optional attribute; **read/write** access; type: **[[sos]*]**.

List of connections for the component. The format is a list of lists, each containing the name of the connector, the connected component, and the name of the connector on the other component.

connectors

Pseudo class attribute; **read-only** access; type: **D**.

Dictionary of dictionaries with connectors defined by this component class, indexed by name. Each connector contains the name of the connector “type”, a “direction” (“up”, “down” or “any”), a flag indicating if the connector can be “empty”, another flag that is set if the connector is “hotplug” capable, and finally a flag that is TRUE if multiple connections to this connector is allowed.

instantiated

Optional attribute; **read/write** access; type: **b**.

Set to TRUE if the component has been instantiated.

object_list

Optional attribute; **read/write** access; type: **D**.

Dictionary with objects that the component consists of.

object_prefix

Optional attribute; **read/write** access; type: **String**.

Object prefix string used by the component. The prefix is typically set by the **set-component-prefix** command before the component is created.

top_component

Optional attribute; **read/write** access; type: **Object**.

The top level component. Attribute is not valid until the component has been instantiated.

top_level

Optional attribute; **read/write** access; type: **b**.

Set to TRUE for top-level components, i.e. the root of a hierarchy.

4.3.2 top-component

Description

Base top-level component class, should not be instantiated.

Attributes

components

Optional attribute; **read/write** access; type: **[o*]**.

List of components below the the top-level component. This attribute is not valid until the object has been instantiated.

cpu_list

Optional attribute; **read/write** access; type: **[o*]**.

List of all processors below the the top-level component. This attribute is not valid until the object has been instantiated.

Chapter 5

Miscellaneous Notes

5.1 Changing the Processor Clock Frequency

The clock frequency of a simulated processor can be set arbitrarily in Simics. This will not affect the actual speed of simulation, but it will affect the number of instructions that need to be executed for a certain amount of simulated time to pass. If your execution only depends on executing a certain number of instructions, increasing the clock frequency will take the same amount of host time (but a shorter amount of target time). However, if there are time based delays of some kind in the simulation, these will take longer to execute.

At a simulated 1 MHz, one million target instructions will correspond to a simulated second (assuming the simple default timing of one cycle per instruction). At 100 MHz, on the other hand, it will take 100 million target instructions to complete a simulated second. So with a higher clock frequency, less simulated target time is going to pass for a certain period of host execution time.

If Simics is used to emulate an interactive system (especially one with a graphical user interface) it is a good idea to set the clock frequency quite low. Keyboard and mouse inputs events are handled by periodic interrupts in most operating systems, using a higher clock frequency will result in longer delays between invocations of periodic interrupts. Thus, the simulated system will feel slower in its user response, and update the mouse cursor position etc. less frequently. If this is a problem, the best technique for running experiments at a high clock frequency is to first complete the configuration of the machine using a low clock frequency. Save all configuration changes to a disk diff (like when installing operating systems). Then change the configuration to use a higher a clock frequency and reboot the target machine.

Note that for a lightly-loaded machine (for example, working at an interactive prompt on a serial console to an embedded Linux system), Simics will often execute quickly enough at the real target clock frequency that there is no need to artificially lower it.

5.2 Manually Testing Interrupts

Interrupts from the interrupt controller comes in to the Simics PowerPC via the `simple_interrupt` interface. To manually trigger an interrupt it is possible issue:

```
simics> @conf.cpu0.iface.simple_interrupt.interrupt(conf.cpu0, 0)
```

The command line triggers the interrupt towards the CPU. The seconds parameter (zero) indicates that this is a normal interrupt. Critical interrupts should use the value 1. The external interrupt will only be serviced (when continuing execution) if the MSR[EE] bit is set, enabling external interrupts. To manually set this bit issue:

```
simics> %msr = %msr | 1<<15
```

To lower the external interrupt manually issue:

```
simics> @conf.cpu0.iface.simple_interrupt.interrupt_clear(conf.cpu0, 0)
```

5.3 Cache Simulation

For generic information on how cache simulation is done in Simics please refer to Simics User Guide.

PowerPC instructions which manipulates the cache directly, such as `dcbf` can effect the cache model provided that the processor's `icache` and `dcache` are properly set.

The `icache` and `dcache` attributes should point to g-cache objects simulating instruction and data cache. For SMP configurations, the `cpu_group` attribute should point to a `ppc-broadcast-bus` object which will be informed about the caches the cpus uses. If the WIMG M-bit is set for a cache transaction, then memory coherency is required and the cache operation is sent down to the broadcast bus which distributes it to all known caches. For non-SMP configurations or if the M-bit is not set, the local cache is called directly.

| | PowerPC operation | Cache Operation |
|---|--|------------------------|
| The following operations are supported: | <code>dcbf</code> (data cache block flush) | Cache_Control_ |
| | <code>dcbst</code> (data cache block store) | Cache_Control_ |
| | <code>dcbt</code> (data cache block touch) | Cache_Control_ |
| | <code>dcbtst</code> (data cache block touch for store) | Cache_Control_ |
| | HID0[DCFI] | Cache_Control_ |
| | HID0[ICFI] | Cache_Control_ |

Other operations, such as locking cache lines, are not currently supported. The cache module receives the the cache operation via the `cache_control` interface.

Chapter 6

Limitations

This chapter contains the limitations that exist on the PowerPC 970fx processor core. The SPRs listed do currently have no associated side-effect when either the register is read or written. In many cases this is not a problem even when code do use these registers.

The instructions implemented as no-operation (NOPs) will just execute without any side-effects at all.

6.1 PowerPC 970fx limitations

6.1.1 Unsupported SPRs

| SPR name | Number | Description |
|----------|--------|--|
| ACCR | 29 | Address Compare Control Register |
| MMCR0 | 795 | Performance Monitor Control Register 0 |
| MMCR1 | 798 | Performance Monitor Control Register 1 |
| MMCR2 | 786 | Performance Monitor Control Register 2 |

6.1.2 Miscellaneous Processor Core Limitations

PMC: Performance Monitor Counters (PMC) are not supported.
Floating-point estimate instructions are not bit exact.

6.1.3 Unimplemented Instructions

None

6.1.4 Instructions Implemented as NOPs

dss[all]

Chapter 7

References

<http://www.busybox.net>

BusyBox combines tiny versions of many common UNIX utilities into a single small executable.

<http://kegel.com/crosstool/>

Useful information and tools for building cross-compilation toolchain.

<http://sourceforge.net/projects/u-boot>

Universal boot loader.

<http://www.amcc.com/Embedded/>

Linux kernel.

<http://www.penguinppc.org>

Linux kernel information regarding PowerPC targets.

Index

Symbols

\$freq_mhz, [9](#)
\$initrd_image, [9](#)
\$kernel_base, [10](#)
\$kernel_image, [9](#)
\$load_base, [10](#)
\$memory_megs, [9](#)
[simics], [5](#)
[workspace], [5](#)

C

component, [15](#)
configuration
 tips, [17](#)
create-std-ethernet-link, [11](#)
create-std-serial-link, [12](#)
create-std-server-console, [14](#)
create-std-text-console, [13](#)

I

info
 namespace command
 std-ethernet-link, [12](#)
 std-serial-link, [12](#)
 std-server-console, [15](#)
 std-text-console, [14](#)
interactive use of simulated machines, [17](#)

N

new-std-ethernet-link, [12](#)
new-std-serial-link, [12](#)
new-std-server-console, [14](#)
new-std-text-console, [14](#)

P

processor clock frequency, [17](#)

S

status

namespace command
 std-ethernet-link, [12](#)
 std-serial-link, [12](#)
 std-server-console, [15](#)
 std-text-console, [14](#)

std-ethernet-link, [11](#)
std-serial-link, [12](#)
std-server-console, [14](#)
std-text-console, [13](#)

T

top-component, [16](#)



Virtutech, Inc.

1740 Technology Dr., suite 460
San Jose, CA 95110
USA

Phone +1 408-392-9150
Fax +1 408-608-0430

<http://www.virtutech.com>